



## Yamaha MT09 Infill Panels 22140 & 22133

### Kit Includes:

**X1 430x5mm cable tie** CAB0430

- Remove seat & pillion foot pegs.
- Put the right hand panel in place and fix using the original bolts whilst making sure that the foot peg is positioned over the mounting tab of the panel. Repeat for the left hand panel.
- Feed cable tie through the slots in the top of each panel, ensuring it runs under the fuel tank bracket.
- Pull cable tie tight.
- Ensure all pillion foot peg bolts are fully tightened.
- Check all fixings periodically.

**sales@pyramid-plastics.co.uk**  
**+44 (0)1427 677990**  
**www.pyramid-plastics.co.uk**



## Yamaha MT09 Infill Panels 22140 & 22133

### Kit Includes:

**X1 430x5mm cable tie** CAB0430

- Remove seat & pillion foot pegs.
- Put the right hand panel in place and fix using the original bolts whilst making sure that the foot peg is positioned over the mounting tab of the panel. Repeat for the left hand panel.
- Feed cable tie through the slots in the top of each panel, ensuring it runs under the fuel tank bracket.
- Pull cable tie tight.
- Ensure all pillion foot peg bolts are fully tightened.
- Check all fixings periodically.

**sales@pyramid-plastics.co.uk**  
**+44 (0)1427 677990**  
**www.pyramid-plastics.co.uk**