

## 22160 Yamaha MT-09 Fly Screen Fitting Instructions

### Kit Includes:

1X	C22160	Fly Screen
1X	CFK22160	Bracket
3X	CBOLM50008	M5 X 16mm Stainless Bolt
3X	CNUTM50001	M5 Rubber Anchor Nut
3X	CWASM50001	M5 Washer
4X	CBOLM60020	M6 X 20mm Stainless Hex Bolt
4X	CWASM60003	M6 Washer
4X	CCAP0001	Bolt Cap

- The Pyramid fly screen is simple to fit. Attach the fly screen to the bracket using the M5 fixings supplied (CNUTM50001, CBOLM50008 & CWASM50001). See Fig 1 and Fig 2 below for images.
- Remove the OEM bolts from the top of the headlight. Retain the flat washers from beneath these OEM bolts for use when fitting the fly screen.
- Now fit the fly screen using the remaining items supplied in the fitting kit (CBOLM60020, CWASM60003, CCAP0001).  
A spanner/wrench will be required in order to access the top of the M6 x 20mm stainless steel hex bolts.

Check fixings periodically.

Fig 1



Fig 2



Fig 3



Any questions?  
[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)  
 +44 (0)1427 677990  
[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)



Follow us on social media and  
 feel free to leave us a review!