

22660 Yamaha MT-10 Headlight Shrouds Fitting Instructions

Kit Includes:

1.	X2	C22660	Headlight Shrouds (pair)
2.	X1	CFK22660A	Bracket (LHS)
3.	X1	CFK22660B	Bracket (RHS)
4.	X4	CBOLM60034	M6 x 12mm Bolt
5.	X4	CNUTM60008	M6 Cage Nut
6.	X1	CTAP0053	Stick-fit Pads (12 set)
7.	X2	CFOA0002	Foam Strip 65mm (130mm total)
8.	X1	CBRA0218	SP Blue Decal (22660B ONLY)

OEM Parts (from the Motorcycle)

9.	X2	OEM M6 Bolt
10.	X2	OEM M5 Bolt

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!

Loosely attach fixings initially - fully tighten once all other steps are completed.

Assembly Instructions

- Start by attaching the stick-fit pads and foam strips to the brackets as shown in **Fig 1**.
- Attach the M6 cage nuts as shown in **Fig 2**. Using a small flat headed screw driver or allen key can help to attach the M6 cage nuts.
- Remove the OEM M5 and M6 fittings from the motorcycle and refit them with the brackets included (see **Fig 3** for positioning). Fully tighten these mounting points before step 4.
- Now check fitment of the headlight shrouds. Once fitment has been confirmed, remove the backing paper and attach the headlight shrouds to the brackets (see **Fig 4**). Be sure to align the headlight shrouds correctly with the mounting points at the rear.
- With the mounting points aligned, install the M6 x 12mm bolts as shown in **Fig 4**.
- Be sure to check fixings periodically.

