

22960 Yamaha MT-09 SP Infill Panels 2024> Fitting Instructions

Kit Includes:

1.	X1	C22960A	Infill Panel (LHS)
2.	X1	C22960B	Infill Panel (RHS)
3.	X2	CWASM100001	M10 Washer

OEM Parts (From the Motorcycle):

4.	X4	M6 OEM Bolt
5.	X2	M10 OEM Bolt

Assembly Instructions

- Begin by removing the rider and pillion seat to gain access to the mounting points shown in 'FIG. 1'.
- Using the M6 OEM Bolts (Item 4) loosely fit the RHS Infill Panel (Item 1) to the mounting points shown in 'FIG. 1'.
- Using the M10 OEM Bolt (Item 5) and M10 Washer (Item 3) loosely fit the RHS Infill Panel to the mounting point shown in 'FIG. 1'. (Note: The M10 washer fits between the bolt and the Infill Panel.
- Once the Infill Panel is in the correct position, fully tighten all fixings.
- Repeat steps 2 - 4 for the LHS Infill Panel (Item 2).
- Once the Infill Panels have been fitted, refit the rider and pillion seat.

OEM M6 Bolts
Mounting Points

OEM M10 Bolt + M10 Washer
Mounting Point

Please Note:

We advise that all fixings
are checked periodically.

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!

FIG. 1

