



## 24090 BMW F900R Fly Screen Fitting Instructions

### Kit Includes:

1X	C24090	Fly Screen
1X	CFK24090	Bracket
3X	CBOLM40006	M4 X 8mm Stainless Black Torx Bolt
3X	CNUTM40002	M4 Nyloc Nut
3X	CWASM40001	M4 Washer

- The Pyramid fly screen is simple to fit. Remove the OEM plastic cowling and fit the bracket supplied as shown below (use original bolts).
- Attach the Pyramid fly screen to the bracket using the M4 fixings supplied. **Fit the bolt at the bottom of the Pyramid fly screen first for easier access.**
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and  
feel free to leave us a review!



## 24090 BMW F900R Fly Screen Fitting Instructions

### Kit Includes:

1X	C24090	Fly Screen
1X	CFK24090	Bracket
3X	CBOLM40006	M4 X 8mm Stainless Black Torx Bolt
3X	CNUTM40002	M4 Nyloc Nut
3X	CWASM40001	M4 Washer

- The Pyramid fly screen is simple to fit. Remove the OEM plastic cowling and fit the bracket supplied as shown below (use original bolts).
- Attach the Pyramid fly screen to the bracket using the M4 fixings supplied. **Fit the bolt at the bottom of the Pyramid fly screen first for easier access.**
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and  
feel free to leave us a review!

