



32101 Yamaha Tracer 9 Rear Peg Blanking Blocks Fitting Instructions

2X Blanking Blocks (pair)

C32101

1X M5 Nyloc Nut

CNUTM50002

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Simply remove the pillion foot pegs and fit blanking blocks using the OEM bolts.

Use the OEM bolt + nut supplied to attach the brake fluid reservoir to the blanking block on the right-hand side of the bike (there is no need to overtighten this fastener).



32101 Yamaha Tracer 9 Rear Peg Blanking Blocks Fitting Instructions

2X Blanking Blocks (pair)

C32101

1X M5 Nyloc Nut

CNUTM50002

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Simply remove the pillion foot pegs and fit blanking blocks using the OEM bolts.

Use the OEM bolt + nut supplied to attach the brake fluid reservoir to the blanking block on the right-hand side of the bike (there is no need to overtighten this fastener).



32101 Yamaha Tracer 9 Rear Peg Blanking Blocks Fitting Instructions

2X Blanking Blocks (pair)

C32101

1X M5 Nyloc Nut

CNUTM50002

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Simply remove the pillion foot pegs and fit blanking blocks using the OEM bolts.

Use the OEM bolt + nut supplied to attach the brake fluid reservoir to the blanking block on the right-hand side of the bike (there is no need to overtighten this fastener).



32101 Yamaha Tracer 9 Rear Peg Blanking Blocks Fitting Instructions

2X Blanking Blocks (pair)

C32101

1X M5 Nyloc Nut

CNUTM50002

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Simply remove the pillion foot pegs and fit blanking blocks using the OEM bolts.

Use the OEM bolt + nut supplied to attach the brake fluid reservoir to the blanking block on the right-hand side of the bike (there is no need to overtighten this fastener).



32101 Yamaha Tracer 9 Rear Peg Blanking Blocks Fitting Instructions

2X Blanking Blocks (pair)

C32101

1X M5 Nyloc Nut

CNUTM50002

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Simply remove the pillion foot pegs and fit blanking blocks using the OEM bolts.

Use the OEM bolt + nut supplied to attach the brake fluid reservoir to the blanking block on the right-hand side of the bike (there is no need to overtighten this fastener).