

35601 Triumph Tiger 1200 Infill Panels Fitting Instructions



Kit Includes:

1X C35601 Infill Panels (pair)

Fitting these Pyramid infill panels is quick and simple.

- Remove the pillion footpegs and re-fit them with the infill panels trapped between the pillion footpegs and the frame mounting points.

Note: the spacers in the pillion footpeg assembly are fitted on top of the infill panels

- Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



35601 Triumph Tiger 1200 Infill Panels Fitting Instructions



Kit Includes:

1X C35601 Infill Panels (pair)

Fitting these Pyramid infill panels is quick and simple.

- Remove the pillion footpegs and re-fit them with the infill panels trapped between the pillion footpegs and the frame mounting points.

Note: the spacers in the pillion footpeg assembly are fitted on top of the infill panels

- Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



35601 Triumph Tiger 1200 Infill Panels Fitting Instructions



Kit Includes:

1X C35601 Infill Panels (pair)

Fitting these Pyramid infill panels is quick and simple.

- Remove the pillion footpegs and re-fit them with the infill panels trapped between the pillion footpegs and the frame mounting points.

Note: the spacers in the pillion footpeg assembly are fitted on top of the infill panels

- Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



35601 Triumph Tiger 1200 Infill Panels Fitting Instructions



Kit Includes:

1X C35601 Infill Panels (pair)

Fitting these Pyramid infill panels is quick and simple.

- Remove the pillion footpegs and re-fit them with the infill panels trapped between the pillion footpegs and the frame mounting points.

Note: the spacers in the pillion footpeg assembly are fitted on top of the infill panels

- Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



35601 Triumph Tiger 1200 Infill Panels Fitting Instructions



Kit Includes:

1X C35601 Infill Panels (pair)

Fitting these Pyramid infill panels is quick and simple.

- Remove the pillion footpegs and re-fit them with the infill panels trapped between the pillion footpegs and the frame mounting points.

Note: the spacers in the pillion footpeg assembly are fitted on top of the infill panels

- Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk

