



## 36050 Triumph Speed Twin Rear Splash Protector Fitting Instructions

### Kit Includes:

1X	C36050	Rear Splash Protector
3X	CBOLM50008	M5 X 16mm Stainless Bolt
3X	CWASM50001	M5 Plastic Washer

- The Pyramid rear splash protector is simple to fit. **Remove the three bolts** from the underside of the license support and **fit the Pyramid rear splash protector to the same three mounting points using the bolts and washers supplied.**
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!



## 36050 Triumph Speed Twin Rear Splash Protector Fitting Instructions

### Kit Includes:

1X	C36050	Rear Splash Protector
3X	CBOLM50008	M5 X 16mm Stainless Bolt
3X	CWASM50001	M5 Plastic Washer

- The Pyramid rear splash protector is simple to fit. **Remove the three bolts** from the underside of the license support and **fit the Pyramid rear splash protector to the same three mounting points using the bolts and washers supplied.**
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

