

36060 Triumph Tiger 1200 Pillion Luggage Rack Fitting Instructions

Kit Includes:

1X	C36060	Luggage Rack
5X	CFK36060	Brackets (5 parts)
9X	CBOLM50005	M5 x 12mm Bolt
2X	CBOLM50008	M5 x 16mm Bolt
26X	CWASM50002	M5 Washer
11X	CNUTM50002	M5 Nyloc Nut
1X	CTRIM0003	Pre-fitted with glue by Pyramid Rubber Trim (40mm length)

Assemble the brackets as shown in **Fig 1**.

Attach the brackets to the luggage rack as shown in **Fig 3 & 4**.

Remove the pillion seat from the bike and remove the 4 rubber feet on the inside of the pillion seat. Fit the 4 rubber feet to the bracket assembly as shown in **Fig 3** (rubber feet highlighted in **RED**).

Once the pillion luggage rack is fully assembled simply fit in place of the pillion seat.

