



## Instructions:

Build your own high performance, low riding longboard. With a good cutting tool (bandsaw, jigsaw, lightsaber, etc), use the included stencil template to trim the nose and tail of your deck (it will almost certainly need it to fit the brackets).

Sand the edges, apply griptape as needed, mount **all** the skate hardware. The brackets attach under the deck and the truck baseplates should be placed on top of the brackets. Ride off into the sunset.

Note: For 105mm wheels we recommend cutting along the 23° angle. For wheels smaller than 85mm the 16° angle should suffice. Once again, these are recommend for Reverse Kingpin Trucks like Paris and Caliber.

This stencil is also available as a pdf download at [loadedboards.com/zbrkt](http://loadedboards.com/zbrkt)