

Alto Trailer Awning Front Wall

by PahaQue Wilderness, Inc
Installation Instructions



1. Unpack the Front Wall and locate the top of the wall.
2. Starting with the top, begin connecting the Wall to the Awning using the toggle fasteners attached to both pieces. (Photo A)



3. Once the Wall is fully connected, you can stake down the wall for added stability.

4. The Wall door can be opened and tied back when desired. (Photo B)



For additional information, to register your product, or for warranty claims please visit

www.pahaquecustom.com or www.pahaque.com.

PahaQue Custom Shop | 13125 Danielson St #105 | Poway, CA 92064 | 888.700.TENT (8368)

