

PahaQue Custom Shop, Inc

A-Frame Awning

SET UP INSTRUCTIONS



First Time Installation: (If you have already installed your awning, skip to step #5)

1. Locate the two long strips of 'hook' Velcro. You will attach one to each of the Top Edges of the sidewall. Be sure to attach to the sidewall where the trailer door is located.
2. Wipe off the Top Edge of the sidewall with glass cleaner and a soft rag.
3. With the sidewall in the lowered position, and starting at the Lower Corner of one of the sidewall Top Edges, apply the Velcro, peeling off the backing as you proceed along the edge, moving toward the wall peak.
4. Repeat this process on the other Top Edge of the sidewall.

Awning Set Up Procedure: (Follow these steps after initial installation is complete)

5. With the trailer sidewall still in the lowered position, locate the center on the edge of the awning that has the Velcro sewn in.
6. Put the center in the awning edge over the sidewall trim at the peak.
7. Next attach both top edges of the awning to the Velcro which you installed on the sidewall Top Edge.
8. At this time, erect the trailer sidewall, and be sure to properly lock into place.
9. Assemble the longest of the three aluminum poles. Insert this pole into the pocket along the front edge of the awning.

10. Now assemble the two side poles. The end of the pole with the tip fits into the grommet on the corner of the awning. The opposite end of the pole secures to the trailer using the pole brackets (provided).
11. The 1 inch webbing strap also attaches to the trailer, by snapping the hook into the D-Ring located on the pole bracket.
12. Once both straps are connected, be sure to adjust the tension so that it is tight, **This Step Is Critical in Ensuring That the Awning is Secure to the Trailer in the Event of Windy Conditions!**
- ** *This step is critical to ensure the safety of yourself and others, as well as to prevent possible damage to your trailer in high-wind conditions. Damage that results from failure to follow this step is **not** covered by warranty.*
13. We also recommend that you secure the reflective/adjustable guy-lines to the ground using ground stakes (provided).

USEFUL TIPS:

- While taking care not to over-tighten the adjustable webbing straps, it is important to not allow the Awning to sag where water could collect during a rain storm
- Do not store your Awning while wet for any extended period – always dry completely prior to long-term storage.
- Note that the pockets for the aluminum roof pole may need to be sealed around the seams. Use the enclosed Seam Grip® Seam Sealer.

You can register your product online by visiting www.pahaque.com, or by calling us toll-free at **1.888.700.TENT** (8368).

