### PahaQue Wilderness, Inc

# T@B 400 Trailer Awning

SETUP INSTRUCTIONS



\*Note: Products subject to change.


Thank you for purchasing the T@B 400 Trailer Awning, another quality product Made in the USA by PahaQue Custom Shop. This product will provide you with years of service, and is backed by our Lifetime Warranty against any and all defects in materials and workmanship. When used and cared for properly, this product will provide many years of reliable service.


#### A FEW QUICK NOTES:


- **SET-UP----**Your awning can be easily set-up in 5 minutes or less by one or two people, if you follow the basic sequence detailed below. If time allows, we would recommend that you read through these instructions in their entirety and do a practice set-up at home before heading into the wilderness. Then you can be sure all components are present & functional, and proceed through the set-up sequence at a leisurely pace to learn the most efficient techniques.
- **TAKE DOWN** --- For the take down, simply reverse the set-up sequence.
- **LONG TERM STORAGE** --- Your T@B 400 Trailer Awning is more likely to be damaged by mold, mildew or bacteria during storage than by elements while set up and in use. Make sure that all food or other organic material is removed, and that your tent is thoroughly dry before packing into the stuff bag. If you have to pack up and leave the campsite while your tent is damp, set it up later at home & allow it to dry thoroughly for long-term storage.

## How to install your T@B 400 Trailer Awning by PahaQue

- 1. **Locate** the following parts included with your T@B 400 Trailer Awning:
  - Awning Body
  - One Fiberglass pole
  - 1 Aluminum Roof Pole
  - Ground Stakes 8
  - Two Guy Lines
- 2. **Unfold** awning and locate keder cord edge of awning. Make sure awning is right side-up by checking that the coated (shiny) side of the awning fabric is facing downward. See Photo A.
- РНОТО А
- 3. **Starting** at the rear of the trailer, slide the keder cord into the keder rail on the passenger side of your trailer. Make sure that the keder cord is able to feed freely into the rail as you pull the awning towards the front of the trailer. Due to varying keder rail lengths, the keder cord may not be the exact length of the keder rail and this is normal.
- 4. **Locate** the pole sleeve (black fabric) on the outer edge of the awning. Carefully insert the fiberglass pole into the pole sleeve, until there is approximately 18" extended from each end of the sleeve. See Photo B.
- 5. **Starting** at one end, insert the pole tip into the grommet on the webbing at the lower corner of the awning, as shown in Photo C.
- \*Note: The elastic loops/toggles along the inside front seem and support pole are for the optional Front Wall accessory.







- If you have difficulty sliding the keder through the rail, a little dish soap will help without damaging the awning.
- While taking care not to over-tighten the adjustable webbing straps, it is important to not allow the awning to sag where water could collect during a rain storm
- Do not store your awning while wet for any extended period always dry completely prior to long-term storage.

You can register your product online by visiting **www.pahaque.com**, or by calling us toll-free at **1.888.700.TENT** (8368).

#### !CAUTION!

The effects of wind and rain on the Awning are unpredictable. Damage to the trailer and/or Awning may result. Please remove the Awning in heavy wind or rain. Damage due to weather is not covered by your warranty.

