

A DIVISION OF:
ACERBO'S AUTO TRIM
& LETTERING, INC.

ACERBOS.COM



Thank you for choosing our for your vehicle!

We are committed to providing you with the highest level of customer satisfaction possible. If you see room for improvement, please let us know. We recommend professional installation for larger decals if you are unsure of your ability to install. If for any reason you have questions or comments, we would be delighted to hear from you.
Have a special request? You name it, we make it!

LOCAL TO NEW JERSEY, USA? Check out our website WeStripeAnyCar.com for installation!

You can contact us at info@acerbographix.com or call at 856-273-8847

Please remember to check out the rest of our graphics in our store at www.AcerboGraphix.com.

Show us your final product! Take a photo and SEND it, POST it, or TAG us @acerbo_graphix on Instagram, and Acerbo's Auto Trim & Lettering on Facebook.

Again, thank you for your purchase. I hope you enjoy the product!

AcerboGraphix Team



Avery Vinyl WET Installation Instructions
READ INSTRUCTIONS CAREFULLY BEFORE STARTING!!!

INSTALL IN A COOL & CLEAN LOCATION – **DO NOT INSTALL IN DIRECT SUNLIGHT!** Beware of stretching the Vinyl.

Step 1: Clean area on car with alcohol to remove any wax and dirt. This material is meant for wet application.

*Installation mixture: Mix. 16 oz. of water, and & 1ml of baby shampoo in a trigger type spray bottle. The vehicle surface temperature should be between 65 – 90 degree F. DO NOT allow the backing paper to get wet! This will require some drying time once finished.

Step 2: TEST FIT. This will allow you to see where the decal goes on the car and how you need to curve it to fit best. Confirm decal placement by placing it onto desired area.

NOTE: IT MAY BE HELPFUL TO HAVE ANOTHER PERSON FOR ASSISTANCE WITH LONGER DECALS

Step 3: Remove backing paper from the vinyl. Spray both the vinyl underside (sticky side) and the area on the vehicle with the soapy solution.

Step 4: Apply graphic to car (leave the top protection tape till finished). Spray the masking tape with the solution, then with a squeegee, or credit card (non-scratching edges) should be used to press down graphic to eliminate air-pockets/bubbles and push out the soap mixture. START PRESSING FROM THE CENTER OF THE GRAPHIC OUT TO THE EDGES

Step 5: Dry the area around the graphic and remove the covering masking tape in a slow pulling motion at a 180-degree angle careful not to pull up the decal. Use a Squeegee or credit card (that will not scratch the vinyl) to press down the graphic as you go.

Step 6: Continue until graphic is completely installed.

Step 7: The graphic should be kept clean and NO harsh chemicals used on it. Spray wax would be recommended over a paste style wax if desired. Repeat for each decal. Take a photo and share it with us!