ACEIDO GUSTOM DECALS & GRAPHICS



ACERBOS.COM

Thank you for choosing our for your vehicle!

We are committed to providing you with the highest level of customer satisfaction possible. If you see room for improvement, please let us know. We recommend professional installation for larger decals if you are unsure of your ability to install. If for any reason you have questions or comments, we would be delighted to hear from you. **Have a special request? You name it, we make it!**

LOCAL TO NEW JERSEY, USA? Check out our website **WeStripeAnyCar.com** for Professional Installation!

You can contact us at <u>info@acerbographix.com</u> or call at 856-273-8847 *Please remember to check out the rest of our graphics in our store at <u>www.AcerboGraphix.com</u>.*

Show us your final product! Take a photo and SEND it, POST it, or TAG us @acerbo_graphix on Instagram, and Acerbo's Auto Trim & Lettering on Facebook.

Again, thank you for your purchase. I hope you enjoy the product! AcerboGraphix Team

Stripe Installation Instructions READ INSTRUCTIONS CAREFULLY BEFORE STARTING!!!

Step 1: Clean area on car with alcohol to remove any wax and dirt. DO NOT APPLY IN DIRECT SUNLIGHT! (If you prefer, a soap and water mixture may be applied to the vehicle to make placement easier. DO NOT allow the backing paper to get wet! This will require some drying time once finished. The mixture should be a drop or two of soap in a spray bottle full of water. It does NOT need much soap!)

Step 2: TEST FIT. This will allow you to see where the decal goes on the car and how you need to curve it to fit best. Confirm decal placement by placing it onto desired area.

NOTE: IT MAY BE HELPFUL TO HAVE ANOTHER PERSON FOR ASSISTANCE WITH LONGER DECALS

Step 3: Using a tapeline along a straight edge of the graphic may help you stay straight when you apply the graphic.

Step 4: Tape the graphic in place, if not using water and soap, and (starting at one end) peel a small portion on the backing paper away and apply graphic to car (leave the top protection tape till finished). A squeegee, or credit card should be used to press down graphic to eliminate air-pockets/bubbles.

Step 5: Once that portion is securely on the car, reach under the graphic and pull the backing paper further down the graphic and apply that section. Squeegee down the graphic as you go.

- **Step 6:** Continue until graphic is completely installed.
- **Step 7:** Re-squeegee the entire graphic to be sure no areas were missed.

Step 8: (Not all Decals have Transfer Paper) Remove the transfer/protection tape in a smooth motion, left to right. Be sure the graphic remains on the vehicle at ALL times.

Step 9: The graphic should be kept clean and NO harsh chemicals used on it. Spray wax would be recommended over a paste style wax if desired. Repeat for each decal. Take a photo and share it with us!