

6: ATTACH POCKET CLIP



Attach the pocket clip using the screws provided.

Congratulations! You have a brand new knife!

Thank you for purchasing your kit from Jantz Supply!

If you have questions, need replacement parts or are ready to order more knife making supplies, give us a call 800-351-8900.

You can also shop online any time, day or night.



SS1876 HONEY BADGER FLIPPER LOCKING LINER



The only tools needed to complete your kit are T6 & T8 Torx drivers from our set # HK130 and 3M Blue Blade Tape Item # IR981.

1: SAFETY FIRST- MASK THE BLADE

All kit blades from Jantz Supply are pre-sharpened. To avoid any accidents, tape your blade with Blue Blade Tape so the edge is secure.

2: LAYOUT PARTS & IDENTIFY THEM



3: ASSEMBLE THE LINER LOCK TO RIGHT HANDLE



Start with the right handle (the one with pocket clip screw holes) and the liner with the locking mechanism.

Place the liner on the handle so the shapes match and attach the stand offs to the liner and handle using two of the handle screws.

Push the pivot pin (female) through the pivot hole and place the bushing over it.

4: SET BLADE, STAND OFF, AND BUSHING INTO PLACE

Place the blade over the pivot pin and then place the bushing over the pin.

Place the stop pin in the hole under the pivot pin.



5: ATTACH LEFT LINER TO ASSEMBLY



Place the left liner onto the assembly while lining up the stop pin, stand offs, and pivot pin holes.

Be sure all are properly aligned and the stop pin is set into the recesses on both liners.

6: SECURE FINAL HANDLE TO LINER



Place remaining handle on top and set liner holes onto stop pin and stand offs. Liner and handle will lay flat against each other when set correctly.