




VOLANT COOL AIR INTAKES
 PART NO.: 16861
 INSTALLATION INSTRUCTIONS
 WWW.VOLANT.COM
 TECH SUPPORT: (909) 481-3888

16861 PARTS LIST					
1	VOLANT FILTER BOX	2	1/4" WASHERS	1	1/2" X 7" BREATHER HOSE
1	VOLANT FILTER BOX LID	1	1/4" LOCK WASHERS		
1	VOLANT AIR DUCT	4	1/4"-20 TRUSS HEAD SCREWS		
1	RAM FILTER W/CLAMP	4	1/4" RUBBER WASHERS		
2	#056 CLAMPS	1	BR19846C BRACKET (SHORT)		
1	3 1/2" X 2 1/2" SLEEVE	1	1/2" RUBBER GROMMET		
1	1/4"-20 BOLTS	1	1/2" STRAIGHT FITTING		





Volant Performance
 Rancho Cucamonga, CA 91730
 (909) 481-3888 Tech Support
 (909) 476-1491 Fax
 www.volant.com

READ INSTRUCTIONS THOROUGHLY BEFORE DISASSEMBLING. DO NOT SKIP ANY STEPS. ANY QUESTIONS ON A VOLANT KIT MAY BE REFERRED TO OUR TECH SUPPORT LINE AT (909) 481-3888 OR VISIT OUR WEBSITE AT WWW.VOLANT.COM

INSTALLATION INSTRUCTIONS PART NO. 16861

Installation Instructions:

1. Disconnect the negative battery cable
2. Remove the engine cover by pulling up
3. Pull stock breather hose located out of the factory box
4. Remove the factory 10mm bolt holding the box down located on the core support
5. Remove the air temp sensor by gently pulling STRAIGHT out
6. Loosen the factory clamp holding on the factory air duct onto throttle body by using a 5/16 socket or nut driver or flathead screwdriver
7. Remove the factory box and duct
8. Remove the rubber grommet from the bottom of the factory box
9. Prior to installing Volant box put the Volant fitting inside of the factory rubber grommet and install on the Volant box by pressing the grommet through hole in box
10. Prior to installing Volant box install the smaller L bracket to the Volant box using a ¼ lock washer ¼ washer and a 12mm bolt
11. Place Volant box in factory position and tighten down box with the factory 10mm bolt
12. Place the ½ straight fitting into the Volant duct, than the Volant ½ sleeve than the Volant ½ fitting IE duct-fitting-breather hose-fitting
13. Place the 3 ½ X 2 ½" sleeve on the Volant duct and tighten with a #56 clamp using a 5/16 socket or nut driver or flathead screwdriver
14. Place the Volant filter through the hole in the box and clamp to the Volant duct using a 5/16 socket or nut driver or flathead screwdriver
15. Place the open end of the 3 ½ X 2 ½ sleeve onto throttle body and tighten the #56 clamp using a 5/16 socket or nut driver or flathead screwdriver
16. Place the factory breather hose onto the Volant ½ hose fitting
17. Place the stock air temp sensor into the ½ rubber grommet on the Volant duct
18. Attach lid to box with four truss head screws with rubber washer with Phillips screwdriver.
19. Re-install the factory engine cover by pressing down on factory mounts
20. Reinstall the negative battery cable

WARNING: OVER TIGHTENING HARDWARE MAY ALTAR THE INTEGRITY OF THE VOLANT AIR INTAKE SYSTEM.

BEFORE ROAD TESTING

1. Start engine, leaving the transmission in park and securing the parking brake.
2. Make sure to look and listen for any unusual noises or air leaks. Repair problems if needed.
3. Once completed it will be necessary to check periodically for realignment and tightening of all connections.
4. Once all tests are completed, enjoy the performance of your new Volant Air Intake System.

CARE AND CLEANING

Check the cotton reusable filter periodically and remove any excessive dirt build-up by tapping the filter on the ground and brushing off the loosened dirt. Clean the filter by using Volant's Filter Recharger Kit. Volant's Filter Recharger Kit is designed to restore original air flow. Re-oil every 10,000 miles without cleaning to improve filtering in sand and dirt. Clean only when dirt is very excessive or 50,000 miles.

RECOMMENDED SERVICE PARTS

RECOMMENDED SERVICE PARTS	PART NO.
REPLACEMENT FILTER	5125
PREFILTER	51908
CLEANIEG KIT	5100

APPLICATION GUIDE

MY	MAKE	MODEL	ENG.
04-09	DODGE	MAGNUM	6.1L
04-09	CHRYSLER	300	6.1L
05-09	DODGE	CHARGER	6.1L

INSTALL

