

Fast Fit 56057

Dodge
2009 - 2012 Ram 5.7L

1. Disconnect the negative battery cable.
2. Remove the factory engine cover.
3. Loosen the clamp holding the duct to the throttle body and the clamp holding the duct to the air box. Unsnap the ATS sensor harness from the sensor. Remove the air duct.
4. Remove the ATS sensor from the factory air duct.
5. Unsnap the clips from the air box, Remove the breather hose than remove the box top and filter.
6. Press the sensor into the 1/2 grommet on the Volant duct.
7. Attach filter 5118 to the Volant system.
8. Place the Volant hose onto the duct and tighten the clamp.
9. Slide the Volant system onto the throttle body and clip the heat shield into place.
10. Tighten the Volant system to the throttle body.
11. Replace the factory abs breather hose with the supplied line and fittings.
12. Reinstall the factory engine cover.
13. Reattach the negative battery cable.

Volant Cool Air Intakes Tech Support Line (909) 481-3888

