

Fast Fit 58857

Toyota

Tundra 2007 - 2013 5.7L

Sequoia 2008 - 2013 5.7L

1. Disconnect the negative battery cable.
2. Lift up and remove the factory engine cover.
3. Disconnect the MAF sensor connection and remove the harness from the air box.
4. Remove the two breather hoses from the factory air duct.
5. Loosen the clamp holding the duct to the throttle body and the clamp holding the duct to the air box, Then remove the factory ducting.
6. Unsnap the factory air box top and remove, Remove the factory filter.
7. Remove the MAF sensor from the factory box and remove the sensor O-ring.
8. Attach the sensor to the Volant system using the gasket and hardware provided.
7. Attach filter 5117 to the Volant system.
8. Place the reducer onto the Volant system and tighten the #64 clamp.
9. Slide the Volant system onto the throttle body and onto the factory air box.
10. Tighten the Volant system to the throttle body with the #56 clamp and snap the factory box to the heat shield.
11. Attach the 3 in breather hose extension to the volant duct and attach to the factory line using the 1/2 straight fitting.
12. Attach the 1/8 breather line by pressing onto the Volant fitting.
13. Reattach the negative battery cable.

Volant Cool Air Intakes Tech Support Line (909) 481-3888