

Fast Fit 59535

Ford
2011 F150 3.5L

1. Disconnect the negative battery cable.
2. Loosen the clamp holding the ducts to the intake tubes and the clamp holding the duct to the air box.
3. Remove the breather hose from the air duct than remove the duct.
4. Unsnap the MAF sensor harness from the sensor than remove the sensor from the air box.
5. Unsnap the clips from the air box than remove the box top and filter.
6. Attach the sensor into the Volant duct using the gasket and hardware provided.
7. Attach filter 5117 to the Volant system.
8. Attach the hump hose to the Volant heat shield and tighten the clamp.
9. Place the heat shield onto the factory box and tighten down with the factory clips.
10. Attach the sleeves to the Volant duct and tighten the clamps.
11. Slide the Volant system onto the intake tubes and heat shield.
12. Tighten the Volant system to the intake tubes and heat shield.
13. Press the factory breather hose onto the Volant duct.
14. Clip in the MAF sensor harness onto the sensor.
15. Reattach the negative battery cable.

Volant Cool Air Intakes Tech Support Line (909) 481-3888

