

P/N 725857

87-95 C/K 4.3, 5.0, 5.7L 94-95 S10 4.3L

- 1. Disconnect the negative battery cable. Remove the factory air cleaner.
- 2. Remove the 3 bolts holding the throttle in place.
- 3. Remove the bracket holding the fuel lines in place, You do not need to remove the fuel lines.
- 4. Remove the factory gasket between the throttle body and intake manifold.
- 5. Place a gasket on each side of the spacer and slide the assembly between the throttle body and manifold.
- 6. Tighten the spacer into place using the hardware provided. The drilled and tapped bolts are used in the rear of the throttle body for vehicles with two air cleaner studs.
- 7. Check linkage for proper travel some adjustment may be required.
- 8. Reinstall the factory air cleaner, fuel line bracket and battery cable.