



Throttle Body Spacer Installation Instructions

Installation Instruction

09-12 Dodge Ram 5.7L

2009 Dodge Durango 5.7L

2009 Chrysler Aspen 5.7L

Part Number # 726057



Part List :	Tools Required For Installation:
<ol style="list-style-type: none">1. Vortice Spacer2. Gasket3. 6mm x 63mm x 44. 6mm Washers x 4	<ol style="list-style-type: none">1. 5/16, 10mm Socket2. Ratchet & Extension



1. Disconnect air temp sensor on the air duct.



2. Loosen the hose clamps on the air duct located on the filter box and throttle body and remove the air duct.



3. Remove engine shroud. Pull it up off the rubber grommets and away from the hooks.



4. Unscrew the 4 bolts from the throttle body using a 5/16 or 10mm socket.



5. Insert the o ring onto the Volant Vortice then install the spacer into the intake manifold. Make sure the o ring is on the top side.



6. Reinstall the stock throttle body, engine cover and air duct **DO NOT OVER TIGHTEN THE BOLTS ON THE THROTTLE BODY**

Thank you for purchasing our Vortice throttle body spacer. Visit our website at www.volant.com to see our newest product for your vehicle



Volant is a division of tree loft, Inc
10285 Indiana Court Rancho Cucamonga, Ca 91730
BUS (909) 481-3888 FAX (909) 987-8051 www.volant.com