

# Installation Instructions for Part Number 729846

## Ford Mustang SOHC 99-04 4.6L



1. Disconnect the negative battery cable and loosen the clamps holding the factory duct in place.



2. Remove the factory breather hoses.



3. Remove the factory air duct.



4. Remove the 4 bolts holding the throttle body in place.



5. Remove the factory throttle body gasket.



6. Remove the 2 bolts holding the throttle cables in place.



7. Place a gasket on each side of the spacer and install with the curved edge of the fins facing the throttle body.



8. Place the 5/8 fitting into the factory air duct nearest the throttle body.



9. Reattach the factory air duct and breather hoses. Use the 5/8 breather hose to connect the factory hard line to the fitting installed in step #8.



10. Install the cable extension bracket into the factory location using the supplied allen screws.



11. Attach the cable bracket onto the extension plate using the provided bolts.

12. Reconnect the negative battery cable and check the clearance for the throttle cables before driving the car.