CROSLEY

INSTALLING CARTRIDGES FOR NP1 AND NP-6 NEEDLES

STEP 1

Gently pull the current cartrdige away from the tonearm.



STEP 2

The wires need to be installed in same location on new cartridge. Remove current cartridge by pulling off one wire at a time and placing it into the same location on new cartridge. Ensure the wires are not twisted. It's possible the silver attachments on original cartridge come off as well when removing wire, ensure they are removed from wire housing before installing into new cartridge.



STEP 3

Fit the tip of the tone arm into cartridge. The cartridge will have indentation on the top to accept tone arm tip.



STEP 4

Snap into place by pinching both the cartridge and tone arm together.



