



51-53 Nissan Drive  
 Dandenong South, Vic 3175  
 Ph: 03 9791 4350  
 sales@transportequip.com.au

<u>Daily Checks</u>				
Drain water and condensation from the air system Ensure the air reservoirs have reached their operating pressure Check airbags have pressurised				
<u>Maintenance</u>		On Delivery	After 1st Trip	Every 6 Months
Visual inspection of all components for damage and wear		●	●	●
Check condition of airbags		●	●	●
Check shock absorber mounting bolts for correct torque				
M16 = 200Nm		●	●	●
Check U Bolts for correct torque				
3T Axle - M16 = 400Nm		●	●	●
5T-6T Axle - M20 = 500Nm		●	●	●
Check pivot bolts for correct torque				
M27 = 1,000Nm		●	●	●
When mounting a new trailing arm				
M27 = 200Nm plus 270° turn		●	●	●
Check air bag mounting				
M10 = 25Nm		●	●	●
M12 = 35Nm		●	●	●

22/06/2022