

# Sportster Horseshoe Oil Tank

**Lowbrow Customs #010404.** The tank kit has mounting tabs that requires welding to the frame to complete installation:

- Install the top and bottom mount tabs on the oil tank with the supplied rubber grommets, spacer collars, bolts and washers.
- Position the top of the tank for clearance to the frame backbone, typical clearance is 1/8"-3/16". Remove and trim the tabs as needed to fit between the frame tubes.
- Place small tack welds to secure the mount tabs. Too much heat will melt the rubber grommets, so take your time.
- Remove the tank and grommets to finish weld the mounting tabs.

