

COLONY

INSTRUCTIONS - PUSHROD COVER ADAPTOR KIT - COLONY PART NO. 2140-40

Instructions for installing aluminum cups, found in P/N 2140-40, to adapt 1990-2003 style one piece pushrod covers to early style two piece pushrod cover

Place stock pushrod retainer over large end of adaptor. Install stock pushrod seal on small end of adaptor. Install adaptor, retainer and seal over tappet bore in crankcase with stock bolt and washer.

DO NOT FINAL TIGHTEN

Assemble rocker arms, pushrods and pushrod tube assemblies and adjust pushrods. Place bottom end of pushrod tube in cup of adaptor. Rotate tube adaptors so that cup surface is as close to perpendicular with pushrod tube as possible. Install pushrod cover clip and final tighten stock pushrod tube retainer bolt.

