EASY INSTALL: Tsunami Fender

• Fits stock '94-'03 H-D XL's • Precision die stamped & CNC laser cut construction • Heavy gauge 606 T-6 aluminum • Available in Raw Aluminum, Black or Silver anodized finishes







"Lose Those Stock Parts..."

- a.) Remove rear wheel.
- b.) Remove seat, & disconnect wiring for rear lights.
- c.) Remove shocks & any trim pieces preventing removal of fender.
- d.) Remove rear fender.





"Cut Through It Like Butter..."

- a.) Decide where you want to cut the strut mounts off.
- b.) Use a cutting wheel, jigsaw or hacksaw to cut the strut mounts.

"Bada-Bing, Bada-Boom! That Was Easy!"





- "Easy, Peezey... We're Almost There..."
- a.) Slide Tsunami Fender into place, insert & tighten the 3 bolts.
- b.) Hook up wiring for your light(s) if you installed any.
- c.) Re-Install rear wheel, shocks & anything else. This is the last step!





RAW ALUMINUM - SKU: 003638





"Time To Clean Her Up!"

- a.) If you so desire, use a grinding wheel to round the edges, and clean up the strut mount arms.
- b.) Use some spray paint to cover up where you've been grinding.
- c.) Now is a good time to install a tail light on your new fender.

