

TRIUMPH 650 SIMPLIFIED WIRING DIAGRAM

NEGATIVE GROUND w/ BATTERY & PAZON or BOYER

