











## Fitting Instructions for the Holden Colorado 7 / Isuzu MU-X Rear Neoprene Seat Cover





*Please read this document in its entirety prior to fitting the seat cover. If you have any specific questions or troubles fitting the seat cover, please contact us first, as we are more than willing to assist with any enquiry.*



	<p>Step 1) Push the front seats as far forward to the front of the vehicle, to ensure an easier fitment of the rear seat cover.</p>
	<p>Step 2) Remove both outer headrests by pressing the button on the right hand side and lifting the headrest until it cannot be raised any further. From there, you will need a pin to press in the dimple on the left hand side, whilst also pressing the right hand side (This is done easiest with 2 people). Raise the headrest until the headrest stalks are removed from the seat. <b>Note:</b> The middle headrest should not be removed</p>
	<p>Step 3a) As per the pictures to the left and below, fit the headrest cover by placing the headrest into the headrest cover. Squeeze the foam in the headrest to make it easier to fit the headrest cover. <b>Note:</b> Please be gentle when fitting the headrest cover, as it is a tight, custom-fit design. THE PHOTOS ARE ILLUSTRATIONS ONLY AND MAY NOT BE THE SAME HEADRESTS COVERS</p>
	

	<p>Step 3b) Secure the touch tape tabs</p>
	<p>Step 4) Place the headrests safely to one side, as they will be re-fitted later on.</p>
	<p>Step 5) <b>60% Backrest Fitment</b></p>
	<p>Step 6a) Fit the neoprene cover over the entire 60% Backrest. Please ensure that the eyelets line up with the headrest stalk holes. You must fit the cover over the top of the middle headrest. Ensure that the seat belt is still accessible (the seat cover should be fitted underneath the seat belt, not over the top). Re-fit the outer passengers side headrest, as this will ensure the seat cover is aligned correctly.</p>
	<p>Step 6b) Fold the seat flat and join the 2 velcro tabs together that are located on the back of the cover. (as per the picture to the left). <b>Note: You will need to remove the protective touch tape first from one side</b> (see below).</p>

	 <p><b>Example only of the back of the seat</b></p> 
	<p>Step 7) Carefully tuck the neoprene between the gap of the backrest and the cushion. This will be used to join the touch tape on the other side of the backrest (see Step 8). <b>Please Note:</b> It is much easier to tuck the material through the gap when the backrest is lowered to a 60-degree angle.</p>
	<p>Step 8) Remove the protective touch tape, to allow both touch tapes (from different sections) to join together. Ensure that all holes and provisions on the back of the cover are correctly lined up, so that the backrest can function as normal. You can now raise the backrest to its original, upright position. <b>Note:</b> Please don't throw away the removed protective touch tape, as it will be necessary to keep in the event that you remove the seat covers – Further details included in '<b>Removal of the Seat Cover – Special Considerations</b>'</p>



	
	<p>Step 9) Ensure that the left and right hand side of the cover, covers the seat fabric (see picture to the left). Ensure enough material is tucked through the gap of the cushion and the backrest, so it doesn't hang freely.</p>
	<p>Step 10) – <b>40% Backrest Fitment</b> – Please follow the exact same steps as the 60% Backrest Fitment – Steps 6 to 9. Exclude Step 6b as this is not applicable for 40% fitment.</p>
	<p>Step 11a) <b>60% Cushion Fitment</b> – This is done easiest by raising the 40% cushion to its upright position (up against the back of the front seat) see picture to the left. After you have raised the 40% cushion upright, place the 60% cushion over the seat. This is done easiest by starting at the middle section and working your way around. Place the seat belt buckle through the hole.</p> 

	<p><b>ALSO IMPORTANT TO NOTE:</b> There is a plastic tab that is located closest to the 40% cushion (centre section). Push the plastic tabs upwards into a slot on the original seat. This will allow the cushion cover to stay in position. (see pic).</p>
	<p>Step 11b) Once the cover seems to be sitting nicely. Remove the protective touch tape that is located at the front of the cover. This will be used to affix to the carpet (see pic to the left). Also ensure that the cover tucks into the plastic trim (closest to the passenger side door).</p>
	<p>Step 12) Prior to pushing the cover through the gap of the cushion and backrest join velcro together near the middle seat belt (see pics)</p> 
	<p>Step 13) Once velcro is affixed in step 12, remove the protective touch tape. Push the excess neoprene through the gap of the cushion and backrest and affix to the carpet on the back of the seat. This is done easiest by lowering the backrest to a 45 degree angle.</p> <p><b>NOTE: It is very tight when trying to attach the Velcro to the carpet. IF YOU ARE HAVING TROUBLE with tucking enough of the cover through,</b></p>

	<p>raise the 60% cushion cover to its upright position (see pic to the left). When it is raised, you can see the carpet (see pic below) and it will enable you to readjust the fit.</p> 
	<p>Step 14) <b>40% Cushion Fitment</b> – Please follow the exact same steps as the 60% Cushion Fitment – Steps 11 to 14. Exclude Step 12 as this is not applicable for 40% fitment.</p>

### Removal of the Seat Cover – Special Considerations

- 1) Removal of the headrest covers – Carefully remove the headrest from the base of the backrest. Once the headrest cover has been removed, please ensure that touch tape tabs are then secured together – This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.
- 2) Removal of the backrest & cushion cover - You must carefully remove the cover evenly on both sides at the same rate. If only one side is raised first, it may result in the stitching tearing (warranty claims will not be accepted if neoprene / stitching is damaged as a result of incorrect removal).
- 3) Removal of the backrest and cushion cover – Once completely removed, re-attach touch tape tabs that were removed. This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.

## **On-going Maintenance / Care Instructions**

- 1) Please use a warm cloth to remove any dirt or grime from the seat cover. Please then allow the seat cover to naturally dry.
- 2) Although our seat covers are incredibly durable, we don't recommend that you vacuum your seat covers. Regular vacuuming over time, may compromise the strength of the seat cover. Please use other suitable methods (such as a dustpan) to remove excessive dust, dog hair etc.