







Please read this document in its entirety prior to fitting the seat cover. If you have any specific questions or troubles fitting the seat cover, please contact us first, as we are more than willing to assist with any enquiry.

	<p>Step 1) Remove headrests</p>
	<p>Step 2) Fit headrest covers and place to one side as they will be fitted at a later stage</p>
	<p>Step 3) Backrest Fitment - Gently place the seat cover over the backrest section. Tuck the holes created in the cover underneath the plastic.</p>
	<p>Step 4) Re-fit headrests</p>
	<p>Step 5) Carefully tuck the neoprene between the gap of the cushion and the backrest.</p>

	<p>Step 6 – Secure the velcro to the velcro on the back of the seat cover. Note: You will have to remove the protective layer in order for it to stick.</p> <p>You will note that on the face of the seat cover, there is a slight exposed area of material, there is no way to avoid this due to the mechanism in the seat which interferes with the seat cover</p> 
	<p>Step 7) Cushion Fitment – Before, you fit the cushion. Ensure that all of the seat belt buckles are out of the way. You can then roughly align the seat cover to the cushion section. Push the dowel pocket through the gap of the cushion and the backrest section</p>
	<p>Step 8) Where required put the seat belt buckles through the holes that have been created in the seat cover. Note: Not all seat belts are required to go through the hole</p>
	<p>Step 9) Remove the protective touch tape layers of velcro and then affix the velcro to the carpet on the side of the seat.</p>

	<p>Step 10a) At the front of the cushion underneath the seat there is carpet that the velcro needs to affix to. The adhesion on this carpet isn't like other parts of the vehicle. It's of critical importance that you pull enough of the neoprene downwards – as per step 10b, otherwise it will not adhere to the carpet.</p>
	<p>Step 10b) Quite a bit of the neoprene needs to be pulled downwards, in order for it to affix to the carpet (as per step 10a). Be careful not to be too aggressive, as it could tear the neoprene</p>
	<p>Step 10c) Some photos of how it should look underneath if affixed correctly. If the Velcro is not sticking to the carpet, it means that not enough of the neoprene has been brought forward. If too much dowel has been fed through the gap in the cushion (as per step 7) it may prevent the neoprene at the front from correctly affixing to the carpet.</p>
	<p>Step 10) How the cover should look once fitted up.</p> 
	

Removal of the Seat Cover – Special Considerations

- 1) Removal of the headrest covers – Carefully remove the headrest from the base of the backrest. Once the headrest cover has been removed, please ensure that touch tape tabs are then secured together – This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.
- 2) Removal of the backrest and cushion cover – Once completely removed, re-attach protective touch tape tabs that were removed. This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.

On-going Maintenance / Care Instructions / Safety Instructions

- 1) Please use a warm cloth to remove any dirt or grime from the seat cover. Please then allow the seat cover to naturally dry.
- 2) Excessive vacuuming can have an impact on neoprene's laminated scrim. Whilst our neoprene is a car company specification neoprene, excessive vacuuming may shorten the life of the product. IT IS STRONGLY suggested that you don't vacuum anywhere near the airbag seams / panels. This may lead to the airbag seams breaking.
- 3) DON'T put the cover in the washing machine. The safest and most effective method is to soak it in a tub / bath with warm soapy water and then allow them to drip dry.

Any further questions please contact:

Andrew Leask
Owner / Director

Global Automotive Accessories
M: 0413 438 874
E: andrew@globalautomotive.com.au