

# AHRENS & VIOLETTE LOOMS

601 Orange Street • Chico, CA 95926 • (916) 345-5767

The Assembly instructions for mounting the tension box on your loom differs slightly from those given here. The reason for this is that there has been a change in the second warp beam bracket since you ordered your loom.

The differences are as follows:

1. In instruction #4 you will have to drill a new hole in your rear vertical members in order to secure the bottom of your new second warp beam brackets with the long 8" bolt.
2. So after you've mounted the brackets and arms with the top bolts, you'll need to get a 21/64" drill bit (hardware store) and drill through the bottom mounting bolt holes of the second warp beam bracket and stiffener and through the rear vertical members so that you can get the 8" bolt through. If your drill bit isn't long enough to drill all the way through, you will have to take the brackets off, drill through the rear vertical and then remount the brackets.

Check with the picture of how it's supposed to look and I doubt if you'll have any trouble, but if you do have any questions don't hesitate to call or write.

Sincerely,

Jon Violette