



**Model: FG-AWS-PBO-P
(NG to LP Gas Conversion Kit)**

THIS CONVERSION KIT MUST BE INSTALLED BY A QUALIFIED GAS FITTER/SERVICE COMPANY. IF YOU DO NOT UNDERSTAND HOW TO COMPLETE THIS PROCESS THEN DO NOT CONVERT THIS APPLIANCE

This LP Kit contains the following: (1) - FG-PBO-LP (primary pilot orifice #76), (1) - Installation instruction
Note: This kit is only for the primary pilot. The secondary pilot does not require changing for LP gas.

TOOLS REQUIRED: Gloves, 11mm & 1/2" open end wrenches

TURN OFF GAS SUPPLY - IF APPLICABLE

STEP 1: Use gloves to hold the pilot assembly head.

STEP 2: Holding the pilot assembly head in one hand, loosen and remove the brass pilot tube nut secured to the pilot orifice marked 74 with a 11mm wrench. Additional tools may be needed to secure the pilot head while loosening fittings. **Note:** In some cases, you may need to use the 1/2" wrench to keep the orifice from turning when removing the pilot nut with the 11mm wrench.




Fig. 1 Shows 11mm wrench removing the pilot tubing.

STEP 3: Use a 1/2" wrench to remove the pilot orifice marked "74". See Fig. 2.

STEP 4: Install the new LP pilot orifice (labeled "76") in place of the Natural gas orifice just removed and secure into place.



Fig. 2 Shows 1/2" wrench removing the pilot orifice.

STEP 5: Using the 11mm wrench reinstall the brass pilot tube nut to the new LP pilot orifice and secure into place.

STEP 6: Install is complete. Pilot assembly is ready to install.



The Natural Gas Main Burner Orifice must be replaced (before or after converting the pilot assembly) with the appropriate LP Main Burner Orifice before operating the fire feature with LP gas.

FOR TECHNICAL SERVICE, CALL: (800) 966-8126

Firegear Outdoors
17322 Gothard St.
Huntington Beach, CA 92647