

Model EP002: MONROE POST

BURIAL INSTALLATION INSTRUCTIONS

1. Dig a 24" deep (for 8' – 10' post) or 36" deep (over 10' post) hole x 12" wide.
2. Fill the hole with concrete leaving approximately 6" clearance for the gas access hole in the post.
3. Place the cap on top of the base. ***Do not tighten any screws in the cap or the base;** this is just to have the cap in place prior to inserting the post.
4. Place your base over the concrete-filled hole.
5. Carefully slide the aluminum post down through the cap and base and into the concrete to just below the inlet supply hole in the bottom of the post.
6. **For Gas:** With the coiled end at the top, slide the copper feedline down through the post and out through the supply hole in the bottom of the post, and then connect it to the main gas supply.
 - a. *Tip:* Have a partner hold the base up while you connect the line.
7. **For Electric:** Feed the wires from the main through the inlet supply hole in the bottom of the post and up to the top of the post.
 - a. *Tip:* Have a partner hold the base up while you connect the line.
7. Tighten the screws in the base section to secure it to the extruded aluminum post, then tighten the screws in the cap.
8. After you have secured the post and are satisfied with the alignment, let the concrete harden before attaching the lamp.
9. For lamp installation, follow the installation instructions packed with the lamp.

