

Reverse Trigger

Compatible with Can-Am X3 & Polaris RZR Side by Sides

Parts list: 1 Reverse Trigger, 3 Bolts with Nylon Nuts, 1 Shrink Tubing.

Need Help? Call Tech Support: (480)-616-2299

Email: info@utvstereo.com

Go to utvstereo.com for colored installation pictures & videos.



INSTRUCTIONS

1. Remove plastics from around the shifter.
2. Position reverse trigger underneath the shifter.
3. Move shifter into the reverse position
4. Position roller of the reverse trigger directly underneath the shifter pressing the roller down.
5. Mark with a sharpie where the 3 holes are positioned on the reverse trigger.
6. Drill 3 holes.
7. Install bolts.
8. Run blue wire to accessory post (bus bar).
9. Run purple wire to head unit, back up camera, or reverse lights.
10. Adjust tension bolts on the side of the reverse trigger and raise the roller until you hear it click when moving the shifter. (You don't want the roller too high, just enough to hear it click.)
11. Tighten tension bolts.