



RACING SPORT CONCEPTS



INSTALLATION GUIDE

CORVETTE C8 HATCH VENTS

STEP 1

OPEN REAR HATCH AND REMOVE THE NINE T25 TORX FASTENERS
(FASTENER LOCATIONS CIRCLED IN ORANGE)

TOOLS: T25 TORX BIT



COVER ENGINE
COMPARTMENT WITH
PACKING BLANKET IN
CASE YOU DROP ANY
FASTENERS

STEP 2

REMOVE OEM HATCH VENTS

TOOLS: NONE



STEP 3

REMOVE THE THREE T25 TORX FASTENERS THAT SECURE METAL GRILLS TO OEM HATCH VENT (FASTENER LOCATIONS CIRCLED IN ORANGE)

TOOLS: T25 TORX BIT



STEP 4

INSTALL METAL GRILLS ON RSC CF HATCH VENT USING THE OEM HARDWARE
(FASTENER LOCATIONS CIRCLED IN ORANGE)

TOOLS: T25 TORX BIT



STEP 5

INSTALL RSC CF HATCH VENTS

TOOLS: NONE



STEP 6

REINSTALL T25 TORX FASTENERS WITH THREAD LOCKER LIKE LOCKTITE BLUE
(FASTENER LOCATIONS CIRCLED IN ORANGE)

TOOLS: T25 TORX BIT, THEAD LOCKER



FUNCTION | FIT | FINISH



SPECIALIZING IN AERODYNAMICS FOR HIGH
PERFORMANCE VEHICLES SINCE 2007

📞 1-800-815-3751

📷 @rsctuning

✉ sales@rsctuning.com

🌐 www.rsctuning.com

📍 470 Schrock Rd Suite D

Columbus, OH 43229

RSC

RACING SPORT CONCEPTS