



# INSTALLATION GUIDE

---

## CORVETTE C8 MIRROR COVERS

# WARNING!!!

## PLEASE READ BEFORE INSTALLING PRODUCT

- ⇒ ALL RACING SPORT CONCEPTS PRODUCTS SHOULD ONLY BE INSTALLED BY CERTIFIED MECHANICS (AUTOMOTIVE TECHNICIANS). ONLY COMPETENT AND EXPERIENCED MECHANICS ARE QUALIFIED TO SPOT TECHNICAL PROBLEMS WITH YOUR VEHICLE OR WITH THE PRODUCT. FAILURE TO HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL CERTIFIED MECHANIC MAY RESULT IN PART FAILURE OR ANY NUMBER OF UNINTENDED CONSEQUENCES.
- ⇒ ALL RACING SPORT CONCEPTS PRODUCTS SHOULD BE TESTED IN A SAFE ENVIRONMENT AFTER INSTALLATION TO ENSURE PROPER INSTALLATION AND FUNCTIONALITY OF THE PRODUCT.
- ⇒ THIS PRODUCT IS NOT INTENDED FOR OFF-ROAD USE.
- ⇒ THE BUYER IS SOLELY RESPONSIBLE FOR THE PRODUCT THEY CHOOSE, AND TO THE SUITABILITY OF THE PRODUCT FOR THE INTENDED APPLICATION.
- ⇒ THESE INSTALLATION INSTRUCTIONS ARE INTENDED TO BE USED BY CERTIFIED MECHANICS ONLY. RACING SPORT CONCEPTS DOES NOT RECOMMEND INSTALLATION BY ANYONE THAT IS NOT A CERTIFIED AND WELL-EXPERIENCED AUTOMOTIVE TECHNICIAN/MECHANIC.
- ⇒ INSTALLATION OF THESE PARTS IS AN AGREEMENT NOT TO HOLD RACING SPORT CONCEPTS, AS A COMPANY, OR ANY OF ITS EMPLOYEES, LIABLE FOR ANY CIRCUMSTANCES OR COSTS THAT MAY ARISE FROM USING ANY OF THESE PARTS.
- ⇒ RACING SPORT CONCEPTS RECOMMENDS INSPECTING YOUR PRODUCTS ON AN ANNUAL BASIS TO ENSURE THAT NO ISSUES ARE DEVELOPING AND ENSURE THAT THE PRODUCT IS PERFORMING AS EXPECTED.

# TOOLS LIST

## C8 SIDE MIRROR COVER INSTALLATION

- TRIM REMOVAL TOOLS
- MASKING TAPE



# STEP 1

## APPLY MASKING TAPE TO MIRROR GLASS AND MIRROR HOUSING

TOOLS: MASKING TAPE



# STEP 2

## REMOVE MIRROR GLASS

ADJUST MIRROR GLASS INWARD UNTIL FULL TRAVEL IS REACHED. GENTLY PULL ON OUTSIDE OF MIRROR GLASS UNTIL IT RELEASES FROM HOUSING AND DISCONNECT ELECTRICAL CONNECTORS.

TOOLS: NONE



# STEP 3

## REMOVED MIRROR GLASS CONTINUED

DISCONNECT ELECTRICAL CONNECTORS CIRCLED IN ORANGE BY GENTLY PULLING ON CONNECTOR UNTIL IT RELEASES

TOOLS: NONE



# STEP 4

## REMOVE MIRROR COVER

USING TRIM TOOL RELEASE TABS CIRCLED IN ORANGE FROM MIRROR COVER HOUSING BY PUSHING UPWARD ON TAB

TOOLS: TRIM TOOL



# STEP 5

## REMOVE MIRROR COVER CONTINUED

GENTLY PULL ON OUTSIDE EDGE OF MIRROR COVER AND ROTATE INWARD UNTIL MIRROR COVER RELEASES FROM HOUSING

TOOLS: NONE





# STEP 6

## INSTALL RSC CARBON FIBER MIRROR COVER

SLIDE MIRROR COVER ONTO HOUSING CONFIRMING THE TAB ON THE INSIDE EDGE IS SEATED BEFORE SEATING REMAINING TABS

TOOLS: NONE



# STEP 7

## INSTALL RSC CARBON FIBER MIRROR COVER CONTINUED

CONFIRM TABS CIRCLED IN ORANGE ARE COMPLETELY SEATED

TOOLS: NONE



# STEP 8

## INSTALL MIRROR GLASS

CONNECT ELECTRICAL CONNECTORS CIRCLED IN ORANGE BY PUSHING CONNECTOR ONTO CONNECTION UNTIL FULLY SEATED

TOOLS: NONE



# STEP 9

## INSTALL MIRROR GLASS CONTINUED

ALIGN TABS CIRCLED IN ORANGE LOCATED ON THE BACKSIDE OF MIRROR GLASS WITH TAB SLOTS ON MIRROR HOUSING INDICATED BY THE ORANGE ARROWS AND PUSH FIRMLY UNTIL GLASS IS COMPLETELY SEATED.



# STEP 10

## REMOVE MASKING TAPE

TOOLS: NONE



FUNCTION | FIT | FINISH

---



SPECIALIZING IN AERODYNAMICS FOR HIGH  
PERFORMANCE VEHICLES SINCE 2007

📞 1-800-815-3751

📷 @racingsportconcepts

✉ sales@racingsportconcepts.com

🌐 [racingsportconcepts.com](https://www.racingsportconcepts.com)

📍 41 Greenscape Ct

Johnstown, OH 43031

**RSC**  
RACING SPORT CONCEPTS