ASSEMBLY GUIDE

Remove all parts from the box, check if there are any missing parts.



Package contents

- 1. 1x Headrest Pad
- 2. 1x Backrest Assembly
- 3. 1x Armrest and Seat Assembly
- 4. 1x Backrest Pad
- 5. 2x Side Cover
- 6. 1x Wheel Stand
- 7. 1x Hydraulic Piston
- 8. 5x Casters
- 9. 4x Screws, washers & screw cap sets (M8 x 30mm x2) $(M5 \times 16mm \times 2)$
- 10.1x Two-way Allen Key
- 11. 1x Adaptor

Notes

- Allow at least 40cm of surrounding space for the chair to prevent obstruction when assembling the chair.
- · Having an additional helping hand will make assembly even easier and faster.

Caution

- · When assembling the chair, the power adapter must be disconnected from the electrical outlet.
- · Assemble the chair on a flat and even surface.
- Place a rug beneath the chair to prevent scratching the chair while assembling.

PREDATOR X OSIM*



Cover metal plate with the left and right side cover on both sides as shown by aligning the side cover stud with the seat base hole. Press and fit them



Align the hole at the base of the seat with the hydraulic piston. Press and fit them together with force.

Ensure the pins of the cable plug on the backrest are straight and aligned to the cable socket at the bottom of the seat base before fitting them ogether. Do not twist or force the plug into the socket. It should fit

Place the wheel stand on a flat surface

right side up and insert the hydraulic

Align the holes on the side cover and

metal plate. Insert screw (M5x16mm)

and tighten with Two-way Allen Key.

piston to its center



USAGE INFORMATION

Ensure chair is plugged in and powered on.

Press button to adjust the armrest height.



Pull lever fully and lean back slowly to recline.



Slide the backrest assembly on the rear side of the seat as shown. Align the screw holes on the metal plate and backrest (2 locations each on the left and right side).



Cover the left and right holes with screw caps



Carefully tilt the chair upright on a flat surface and ensure armrest and seat assembly is secure. Connect the adaptor cable into the socket which is at the bottom of the backrest



Insert screws (M8x30mm) with washer and tighten with Two-way Allen key.



Lift the chair and gently set it facing



Place headrest pad on the top of the backrest and secure with the strap. Adjust backrest pad to your desired position for better lumbar support when seated.



Pull lever up to adjust your preferred chair height.



Slide open the right armrest to access embedded

