



BMW F Chassis Hood Latch Installation Instructions

Disclaimer: This guide is meant to be used as a reference and Carbonex is not responsible for any damage and harm to the vehicle, its component, and the people involved during the installation process. In addition, different vehicle options, build year, and model have different components and certain steps could be different.

Tools required

- Philips head screwdriver

Instructions

1. Remove the philips head screw holding the OEM hood latch handle.



2. Remove the OEM hood latch handle and install the Carbonex billet hood latch handle.



3. Secure the philips head screw and enjoy the premium look and feel of the new hood latch handle.

