



BMW G Chassis Hood Latch Installation Instructions

Disclaimer: This guide is meant to be used as a reference and Carbonex is not responsible for any damage and harm to the vehicle, its component, and the people involved during the installation process. In addition, different vehicle options, build year, and model have different components and certain steps could be different.

Tools required

- Small flat head screwdriver

Instructions

1. Pull the OEM hood latch handle to the full extent



2. The OEM hood latch handle is held in place by a plastic pin



3. Insert a flat head screwdriver in between the pin and the hood latch (sorry for the out of focus photo!)



4. Remove the pin by pushing downwards



5. Remove the OEM hood latch handle



6. Take the Carbonex hood latch handle and make sure all mounting points are aligned



7. Install the Carbonex hood latch handle. Ensure to apply firm pressure until the hood latch handle cannot go any further. When properly installed, the gap between vehicle and hood latch handle should be minimal (~1mm).



8. The Carbonex hood latch handle is secured by a redesigned 3D printed pin.



Notice that one side has the slot reserved for removal using a flat head screwdriver



9. Pull the Carbonex hood latch handle to the full extent and take this pin with the slotted side facing you



10. Gently insert the pin into the hood latch handle. You should hear a click when the pin is fully inserted.



Illustration when pin is fully inserted



11. Enjoy your new OEM+ hood latch handle and thank you again for your continuous support!

