



Xtreme Mats Lite Application Instructions

STORAGE:

- Due to the adhesive backing, Xtreme Mats Lite should be stored in a cool, dry, indoor location until ready to use.

TOOLS:

- Alcohol Wipes
- Clean cloth

PREPARATION:

1. Thoroughly clean the surface area where the mat will be installed with an alcohol based cleanser. The area must be completely dry and free of debris before applying the mat.

APPLICATION:

1. Before removing the adhesive backing, determine the correct fit and spacing for your mat.
2. Turn the mat over with the adhesive backing facing up. Peel off the adhesive backing.
3. Position it where you want the mat installed.
4. Firmly press down on your mat for 15 seconds to secure the bond between the mat and the surface.

CHECK OUT OUR SISTER COMPANY



The Xtreme Mat is the original under sink cabinet mat manufactured for the depth of both kitchen and bathroom vanity cabinets.

Our under sink mats protect your cabinets and floors from damage caused by plumbing leaks, stains, scratches, product or chemical spills, and much more. Xtreme Mats can hold up to 3.6 gallons of liquid in the event of a leak or product spill, making our mats the leader in the industry. Our mats are flexible and produce no toxic VOC's. Xtreme Mats are easy to install and can be removed quickly for clean-up. Receive a free water sensor and free shipping when purchasing directly from Xtrememats.com



@xtrememats

407-392-0950

XTREMEMATSONLINE.COM