


# **INSTALLATION INSTRUCTIONS**

5 INCH OVAL STRAIGHT SIDEBAR 2019-2023 FORD RANGER SUPERCREW CAB 4DR PART# 5S-F1182

TRUCK ACCESSORIES COMPANY

#### **PARTS LIST:**

1	Driver/Left Sidebar	12	10-1.5mm x 25mm Hex Bolts
1	Passenger/Right Sidebar	12	10mm Lock Washers
2	Front Mounting Brackets	12	10mm x 27mm x 3mm Flat Washers
4	Center and Rear Mounting Brackets	12	8-1.25mm x 25mm Combo Bolts



#### PROCEDURE:


- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.
- 2. Starting from underneath the Driver/Left side inner rocker panel, locate the threaded mounting holes on the rocker panel, (Figure 1). Remove the plastic plugs covering the mounting holes. Select (1) Front Mounting Bracket, (Figure 2). Attach to Driver/Left front location with (2) 10mm Hex Bolts, (2) 10mm Lock Washers and (2) 10mm Flat Washers, (Figures 2 & 3). Do not tighten hardware at this time.
- 3. Locate the Center threaded mounting holes. Select (1) Center/Rear Mounting Bracket. Attach with (2) 10mm Hex Bolts, (2) 10mm Lock Washers and (2) 10mm Flat Washers, (Figures 4—6). Do not tighten hardware at this time.
- 4. Repeat Step 3 to install Rear Mounting Bracket, (Figures 5 & 7).
- 5. Unwrap the Driver/Left Sidebar. Attach Sidebar to the mounting brackets with (6) 8mm Combo Bolts. Do not tighten hardware at this time, (Figures 8 & 9). IMPORTANT: Do not slide or rotate Sidebar on cradles, or damage to the finish may result.
- 6. Level and adjust Sidebar and tighten all hardware.
- 7. Repeat Steps 2—6 for Passenger/Right side installation.
- 8. Do periodic inspections to the installation to make sure that all hardware is secure and tight.


**To protect your investment**, Do not use any type of polish or wax that may contain abrasives that could damage the finish. **For Stainless Steel**, Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used to clean the Sidebar.

www.tacautoparts.com Page 1 of 3 03/28/19 (AL)


### **Driver/Left side Installation Pictured**


(2) 10mm Hex Bolts






(Fig 3) Driver/Left Front **Mounting Bracket attached** 







**Mounting Bracket installation** 




## **Driver/Left side Installation Pictured**




Mounting Bracket installed



(Fig 7) Driver/Left Rear **Mounting Bracket installed** 





(Fig 9) Driver/Left Sidebar installed