




Mount **Base** into vent opening. Fasten with screws as needed.




Measure **Body**. If adjustment is necessary, cut along perforated edges according to sizes in step #2.




Peel and stick provided sound dampening strips along the edges of the opening.




Use mud to cover flange surfaces. Wait to dry, then sand. Repeat as needed.




Insert and slide **Tray** into place. Use hole on the side of the **Tray** as a guide.




Measure base of ventilation fan to check if adjustments need to be made to the **Flush Exhaust Mount** opening.



Some fan flanges can obstruct holes needed to slide on the **Tray** (step 8). If this is the case, trim flanges of fan.



Insert and fasten fan with screws. Sound damping strips should be sandwiched between fan and **Body**.



Paint inside of the **Body** and **Tray** to match ceiling colour. Do not paint fan.

