

User Instructions for Hardwire Kit for In-Vehicle Installation
HWKIT-6SCharger



Name	Section (Numbered above)	Length
Charger Cable	1 to 2	36"
Main Cable	2 to 3 and 2 to 5	96" / 120"
Fuse Cable	3 to 6	24"

Remember: Before starting the installation, make sure the cable lengths are long enough that they reach the vehicle battery.

Reference	Installation Instruction
1	Connects to charger base for in-vehicle chargers and single bank.
2	Connects to charger base for 6 bank chargers
3	The connector allows main cable to route through firewall or other small opening allowing access to fuse cable.
4	Holder for replaceable blade fuse.
5	Gather the ring connector to the end of the black wire. Connect to the negative battery terminal.
6	Gather the ring connector to the end of the red wire. Connect to the positive battery terminal or 12V/ 24V power source.

Tip: When routing the cable through the vehicle, or engine compartment, ensure they are secured correctly to prevent grazing of wire insulation. Keep these cables away from any heat source in the engine compartment.