

The Parts.



Note:
3 "K" screws have been attached to the "H" & "I" bolts. Please take them off before assembly.
Approximate Assembly Time: 30 minutes.

The Steps.

1. Connect frame "A" and frame "B" using bolt "H" and secure with screw "K".
2. Attach part "C" to frame "A" with bolt "I". Secure with screw "K".
3. Attach part "C" to frame "B" with bolt "H". Secure with screw "K".
4. Attach the seat cushion "D" to the metal plate on the top of the frame "A". Secure it together with the four "K" screws.
5. Attach knee cushion "E" to frame "B". Secure it in place with four "J" screws.
6. Tightly fasten all the screws completely. Adjust the height of the chair by turning the part "C".

Voila!

You did it! Time to take a load off and begin to reap the benefits of your new Atlanta chair!

If you are missing any parts please contact us at hello@leekform.com

