

Bookcase Bed Assembly Instructions

Contents:

- (A) 1 headboard (43" tall)
- (B) 1 footboard (16" tall)
- (C) 2 bed rails (80" or 85" long)
- (D) 9 slats (twin 40-1/4", full 55-1/4", queen 61-1/4" long)
- (E) 4 connector bolts (100mm long)
- (F) 4 cross dowels
- (G) 18 wood screws (1-1/2" long)
- (H) 4 wood screws (2-1/2" long)
- (I) 1 Allen key

Tools required:

- Slotted screwdriver (use to rotate cross dowel)
- #2 Robertson or Phillips screwdriver



Please read all instructions completely before beginning

1. Assemble the footboard (B) to each bed rail (C) using 4 connector bolts (E) with 4 cross dowels (F). Refer to **Figure 1** for correct position of bed rail, bed end and hardware.
2. Position the bed rails into the headboard (A). Ensure that the bed rails are inserted as far as they will go.
3. Fasten the bed rails to the headboard with two 2 1/2" long wood screws (H) per bed rail through the pilot holes and into the headboard, refer to **Figure 3**.
4. Slats (D) slide into groove of bed rails and must be secured using 1-1/2" screws (G) through pre-drilled holes, refer to **Figure 2**. Begin by positioning a slat in the centre and screwing one end inside the groove. From the opposite side of the secured slat pull slat towards you while pushing second bed rail to secure second end of centre slat while fully inside groove. Once the centre slat is secured at both ends position the remaining eight slats equally with no spaces greater than 3-1/2" and screw into place.

