

## 6045 Desk Return

## Contents:

- A. 6045 Desk Return
- B. 6100, 6200 or 6300 Series Desk
- C. Attachment Block
- D. 6 1 ½" Screws

## **Tools required:**

#2 Robertson or Phillips screwdriver

## Please read instructions completely prior to starting.

- 1. Place desk and desk return in desired location. Ensure that edges of the desk and the return are parallel and tight together.
- 2. From underneath secure the attachment block "C" to the desk return using  $3 1 \frac{1}{2}$ " screws "D". The attachment block should be located so that the remaining pilot holes in the attachment block will allow you to insert the last 3 screws into the underside of the desk top.

