

Mission and Shaker Style Bed Assembly Instructions

Contents: sizes vary depending on model ordered

- (A) = 1 headboard
- (B) = 1 footboard
- (C) = 2 bed rails (75" or 80" long)
- (D) = 9 slats (twin = 40-1/4", double = 55-1/4" queen = 61-1/4" long)
- (E) = 8 connector bolts (70mm long)
- (F) = 8 cross dowels
- (G) = 18 wood screws
- (H) = 1 Allen key

Tools required:

- Slotted screwdriver (use to rotate cross dowel)
- #2 Robertson or Phillips screwdriver

(E) connector bolt (F) cross dowel (G) wood screw (H) Allen key



Please read all instructions before beginning

- Assemble bed using 2 bed rails (C), 1 headboard (A), 1 footboard (B), 8 connector bolts (E), with 8 cross dowels (F). Refer to **Figure 1** for correct position of bed rail, bed end and hardware.
- Slats (D) slide into groove of bed rails and must be secured using screws (G) through pre-drilled holes, refer to **Figure 2**. Begin by positioning a slat in the centre and screwing one end inside the groove. From the opposite side of the secured slat pull slat towards you while pushing second bed rail to secure second end of centre slat while fully inside groove. Once the centre slat is secured at both ends position the remaining eight slats equally with no spaces greater than 3-1/2" and screw into place.

