



Centre Leg Slat Support

Tools Required: #2 Robertson or Phillips screwdriver, tape measure

Parts included:

- 2 Legs
- 2 Mounting blocks
- 1-1/8" Screws

Instructions:

- Install the mounting blocks centred on the bottom side of 2 slats.
- Install these slats in the 3rd and 6th position from the headboard, as shown in the bottom image.
- Position all slats and screw in place.
- Locate the bed as desired.
- Insert the legs in the mounting blocks.
- Adjust the glides to make firm contact with your floor.

Important: To prevent possible damage, remove the legs before moving your bed.

