

## NUGREEN V2 SPUR STRAP INSTALLATION



REMOVE THE EYELET  
FROM OUTSIDE OF SHANK

REMOVE LOWER SPUR  
BOLT

PLACE BACK [THIN]  
WEBBING STRAP HOLE  
OVER EMPTY BOLT HOLE  
THEN BUCKLE (A) OVER TOP

SCREW BOTH ONTO A SHANK  
USING BOLT A AND A WASHER



PLACE BUCKLE (B) OVER THE  
EYELET HOLE AND THE  
FRONT [WIDE] STRAP OVER  
THAT

SCREW DOWN USING BOLT  
(B) WITH A WASHER

ADJUST ANGLES TO FIT  
FEET BEFORE TIGHTENING  
FULLY.

## NUGREEN V2 SPUR STRAP INSTALLATION



FEED THE BACK STRAP  
THROUGH BUCKLE B.

WITH THE SHANK BUTTED  
UP AGAINST THE HEEL OF  
THE BOOT, TIGHTEN AND  
STICK THE VELCRO.

FEED THE FRONT STRAP  
THROUGH BUCKLE A, PULL  
COMFORTABLY TIGHT,

\*THIS DOES NOT MEAN AS  
TIGHT AS YOU CAN\*

STICK THE VELCRO DOWN,  
TIGHTEN TOPS, CLIMB  
TREE.



*NuGreenStore.com*